



Motoazada FANTON SR1Z-45Q

FIG.1 CRANKCASE SUBASSEMBLY. (E01)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E01-1	1310-Z180230-LSA0		CRANKCASE SUBASSEMBLY.	1	1	
E01-2	17004-Z180110-00A0		TUBE, BREATHER	1	1	
E01-3	90007-0612-A1A0		BOLT	3	1	
E01-4	11333-Z180110-00A0		PLATE, BREATH GROOVE COVER	1	1	
E01-5	11332-Z180110-00A0		GASKET, BREATH GROOVE	1	1	
E01-6	90103-0410-51A0		CROSS-RECESSED PAN HEAD SCREW	1	1	
E01-7	11321-Z180110-00A0		BREATH SHEET	1	1	
E01-8	12045-Z240110-00A0		LEAF VALVE STOP PLATE	1	1	
E01-9	90682-Z180110-00A0		SEAL, OIL	1	1	
E01-10	11331-Z180110-00A0		STRAINER, BREATH GROOVE	1	1	
E01-11	19340-Z180110-00A0		SHIELD,LOWER	1	1	
E01-12	19340-Z180211-00A0		SHIELD,LOWER	1	1	
E01-13	90007-0612-A1A0		BOLT	2	1	

FIG.2 COVER SUBASSEMBLY, CRANKCASE (E02)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E02-1	11411-Z180130-YJA0		COVER, CRANKCASE	1	1	
E02-2	90007-0610-A1A0		BOLT	1	1	
E02-3	16400-Z180110-00A0		GEAR ASSY, GOVERNOR	1	1	
E02-4	15010-Z240121-Q5A0		DIPSTICK SUBASSEMBLY, OIL	1	1	
E02-5	90007-0618-A1A0		BOLT	6	1	
E02-6	90007-0650-A1A0		BOLT	2	1	
E02-7	16061-Z180110-00A0		ARM, GOVERNOR	1	1	
E02-8	90408-Z010210-00A0		FLAT WASHER	1	1	
E02-9	90682-Z030210-00A0		SEAL, OIL	1	1	
E02-10	90501-Z010110-00A0		COTTER PIN	1	1	
E02-11	90502-0818-00A0		POSITION PIN	2	1	
E02-12	90682-Z030120-00A0		SEAL, OIL	1	1	

FIG.3 PISTON.ROD, CONNECTING.CRANKSHAFT(E03)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E03-1	13200-Z180120-00A0		RING ASSY, PISTON	1	1	
E03-4	13111-Z180310-00A0		PISTON	1	1	
E03-5	13122-Z350110-00A0		CLIP, PISTON PIN	2	1	
E03-6	13121-Z250110-00A0		PIN, PISTON	1	1	
E03-7	13010-Z180220-00A0		ROD, CONNECTING	1	1	
E03-8	13300-Z180210-00A0		CRANKSHAFT ASSY.	1	1	
E03-9	90408-Z030210-00A0		FLAT WASHER	1	1	

FIG.4 COVER, CYLINDER HEAD(E04)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E04-1	90007-0612-A1A0		BOLT	4	1	
E04-2	12411-Z180110-00A0		COVER, CYLINDER HEAD	1	1	
E04-3	12004-Z180110-00A0		CYLINDER HEAD COVER GASKET	1	1	
E04-4	97002-Z240110-00A0		THROTTLE VALVE ADJUSTING SUBASSEMBLY	2	1	
E04-5	14311-Z180210-00A0		ROCKER, VALVE	2	1	
E04-6	14313-Z240110-00A0		ROCKSHAFT BOLT	2	1	
E04-7	14091-Z180310-00A0		PLATE, LITER LIMITED	1	1	
E04-8	14071-Z180110-00A0		LIFTER, VALVE	2	1	
E04-9	14081-Z240110-00A0		TAPPET, VALVE	2	1	
E04-10	14200-Z180110-00A0		CAMSHAFT ASSY.	1	1	
E04-11	12110-Z240110-00A0		VALVES SET	1	1	
E04-12	12103-Z180110-00A0		SPRING, VALVE	1	1	
E04-13	12103-Z240110-00A0		SPRING, VALVE	1	1	
E04-14	12112-Z010110-00A0		SEAT, VALVE SPRING	2	1	
E04-15	12101-Z010110-00A0		GUIDE, SEAL	2	1	
E04-16	30010-Z180110-00A0		PLUG, SPARK	1	1	

FIG.5 STARTER, RECOIL (E05)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E05-1	28200-Z180220-00A0		STARTER ASSY, RECOIL	1	1	
E05-2	90314-Z130210-00A0		NUT	3	1	
E05-3	28110-Z180220-00A0		SHROUD	1	1	
E05-4	28001-Z180210-00A0		DOUBLE HEAD SUPPORT BOLT	1	1	
E05-5	28001-Z180111-01A0		DOUBLE HEAD SUPPORT BOLT	2	1	

FIG.6 CARBURETOR ASSY.(E06)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E06-1	16004-Z180210-00A0		GASKET, INSULATOR PLATE	1	1	
E06-2	16003-Z180110-00A0		PLATE, CARBURETOR INSULATOR	1	1	
E06-3	16004-Z180110-00A0		GASKET, INSULATOR PLATE	1	1	
E06-4	16001-Z180110-00A0		CARBURETOR SEAL GASKET	1	1	
E06-5	90207-Z180110-00A0		STUD BOLT	2	1	
E06-6	16100-Z181110-00A0		CARBURETOR ASSY.	1	1	

FIG.7 CLEANER COMP, AIR (E07)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E07-1	17100-Z180410-00A0		AIR CLEANER	1	1	
E07-2	90305-0600-31A0		HEXAGON NUT WITH FLANGE	2	1	

FIG.8 MUFFLER (E08)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E08-1	90310-0600-31A0		NUT	2	1	
E08-2	18130-Z180210-H7A0		MUFFLER OUTER COVER	1	1	
E08-3	18100HZ350110-00A0		MUFFLER ASSY.	1	1	
E08-4	18001-Z180210-00A0		GASKET, EXHAUST OUTLET	1	1	
E08-5	18020-Z350110-00A0		PLATE, MUFFLER INSULATOR	1	1	
E08-6	18001-Z350110-00A0		GASKET, EXHAUST OUTLET	1	1	
E08-7	90207-Z180220-00A0		STUD BOLT	2	1	

FIG.9 TANK, FUEL (E09)




REF.NO.	PART NO	CHINSES	DESCRIPTION	Q'TY		ORDER
E09-1	16600-Z180210-Q2A0		TANK ASSY, FUEL	1	1	
E09-2	16730-Z250210-00A0		COVER, FUEL TANK	1	1	
E09-3	90007-0625-A1A0		BOLT	1	1	
E09-4	16652-Z030110-00A0		STRAINER, FUEL	1	1	
E09-5	90685-1000-01A0		PIPE CLAMP	1	1	
E09-6	90686-Z180510-00A0		TUBE, FUEL	1	1	
E09-7	90685-0700-01A0		PIPE CLAMP	1	1	

FIG.10 FLYWHEEL ASSY. (E10)




REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E10-1	13501-Z010110-00A0		NUT, FLYWHEEL	1	1	
E10-2	28002-Z180110-00A0		PULLEY,STARTER	1	1	
E10-3	19352-Z180110-00A0		IMPELLER	1	1	
E10-4	13510-Z180210-00A0		FLYWHEEL SUBASSEMBLY	1	1	
E10-5	90007-0630-A1A0		BOLT	1	1	
E10-6	30400-Z180110-00A0		COIL, IGNITION	1	1	

FIG.11 CONTROL ASSY, THROTTLE. (E11)



REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E11-1	16062-Z180110-00A0		ROD, GOVERNEOR	1	1	
E11-2	16012-Z180120-00A0		SPRING, THROTTLE VALVE RETURNING	1	1	
E11-3	16070-Z180110-00A0		GOVERNOR BRACKET SUBASSEMBLY	1	1	
E11-4	90305-0600-31A0		HEXAGON NUT WITH FLANGE	1	1	
E11-5	16072-Z010110-00A0		BOLT, GOVERNOR SUPPORT	1	1	
E11-6	16063-Z180410-00A0		SPRING, GOVERNOR	1	1	
E11-7	90007-0612-A1A0		BOLT	1	1	
E11-8	16520-Z180140-00A0		CONTROL ASSY, THROTTLE	1	1	
E11-9	90684-Z250110-00A0		WIRE CLIP	1	1	
E11-10	16123-Z180310-00A0		CHOKE PULL ROD	1	1	
E11-11	90007-0625-A1A0		BOLT	1	1	



REF.NO.	PART NO		DESCRIPTION	Q'TY		ORDER
E21-1	RV150MR00W6-TOB301	RV150	Engine	1	1	
E21-2	90521-U050110-00A0		Flat key	1	1	
E21-3	90007-Z030110-00A0		BOLT	1	1	
E21-4	90406-0800-E108		WASHER, FLAT	1	1	
E21-5	90408-1000-E108		FLAT WASHER	1	1	
E21-6	76006-U050110-Q200		SEAT, ENGINE CONNETING	1	1	
E21-7	90310-0800-3108		NUT	3	1	
E21-8	90001-0840-0108		BOLT	3	1	
E21-9	76306-U150110-VC00		BELT GUARD	1	1	
E21-10	90327-0800-3108		HEXAGON NUT WITH FLANGE	4	1	
E21-11	90406-0800-E108		WASHER, FLAT	8	1	
E21-12	90005-0825-0108		HEXAGONAL HEAD BOLT	4	1	
E21-13	76305-U150110-0000		BELT PULLEY	1	1	
E21-14	76210-U150110-0000		TENSION PULLEY ASSEMBLY	1	1	
E21-15	90001-0816-0108		BOLT	6	1	
E21-16	14402-U050110-0000		SPRING, TENSIONER	1	1	
E21-17	76710-U340110-H700		PRIMARY DRY KNIFE COMPONENTS	1	1	
E21-18	24063-U050110-VC00		TRANSMISSION CONNECTION BOARD	1	1	
E21-19	90007-0616-A108		BOLT	1	1	
E21-20	72106-U050110-0000		SPRING, TENSION	2	1	
E21-21	90406-0800-E108		WASHER, FLAT	4	1	
E21-22	90001-0816-0108		BOLT	4	1	
E21-23	90208-U050110-0000		HEXAGONAL STEP BOLT	1	1	
E21-24	90731-U050110-0000		GASKET, RUBBER FLAT	2	1	
E21-25	90325-1000-3108			1	1	
E21-26	76008-U050110-0000		WHEEL, TRANSPORTION	1	1	

E21-27	76010-U050110-H700		TRANSPORTATION WHEEL BEARING ASSEMBLY	1	1	
E21-30	76710-U340110-H700		PRIMARY DRY KNIFE COMPONENTS	1	1	
E21-31	93124-U050110-0100		SOCKET	5	1	
E21-32	90504-U050210-0008		PIN SHAFT	2	1	
E21-33	76016-U050110-0000		DAMPING ARM	1	1	
E21-34	90504-U050110-0000		PIN SHAFT	1	1	
E21-35	90001-1065-0108		BOLT	1	1	
E21-36	90325-1000-3108		HEXAGON LOCK NUT WITH FLANGE	1	1	
E21-37	54200-U330110-VC00		ARMREST ASSEMBLY	1	1	
E21-38	90024-U330110-0000		REINFORCED CUP HEAD SQUARE NECK BOLT	2	1	
E21-39	54124-U040210-0000		HANDLE TUBE REGULATING HANDLE	1	1	
E21-40	90310-0800-3108		HEXAGON NUT WITH FLANGE	1	1	
E21-43	16040-U330110-0000		CABLE ASSY, THROTTLE	1	1	
E21-44	76007-U150110-VC00			1	1	
E21-45	76350-U150110-0000		BOX SUBASSEMBLY, TRANSMISSION	1	1	
E21-47	76305-U150210-0000		BELT PULLEY	1	1	
E21-48	76304-U150110-0000		BELT, DRIVING	1	1	
E21-49	54020-U050110-0000		CABLE, CLUTCH	1	1	
E21-53	16750-U330110-0000		COCK ASSY, FUEL	1	1	
E21-54	90007-0660-A108		BOLT	1	1	
E21-55	90024-U330110-0000		REINFORCED CUP HEAD SQUARE NECK BOLT	1	1	
E21-56	54035-U050210-0000		CLUTCH HANDLE	1	1	
E21-57	54110-U330110-H7A0		HANDLE TUBE ASSY	1	1	
E21-58	54101-U050110-0000		SLEEVE, HANDLE RUBBER	2	1	
E21-66	90310-0800-3108		HEXAGON NUT WITH FLANGE	4	1	
E21-67	76351-U150110-VC00		BOX BODY, TRANSMISSION	1	1	
E21-68	90408-0600-E108		FLAT WASHER	2	1	
E21-69	90408-1000-E108		FLAT WASHER	2	1	
E21-71	76007-U150310-VC00			1	1	

E21-72	76007-U150210-VC00			1	1	
E21-73	90001-0816-0108		BOLT	4	1	
E21-74	90310-0800-3108		HEXAGON NUT WITH FLANGE	4	1	